## Model 1027H Temperature/Humidity Chamber Specifications

Temperature Range	-73°C to +175°C				
Control Tolerance	$\pm 0.5^{\circ}$ C ( $\pm 0.2^{\circ}$ C Typical) (Short-term variations measured at the control sensor after stabilization)				
Uniformity	±0.5°C (Variations throughout the chamber after stabilization)				
Humidity Range	Standard Range: 10% to 95% (Limited by a 6°C dew point and maximum dry bulb of +85°C) With optional GN2 Purge or Dry Air Purge: 5% to 95% (Dry bulb range of +10°C to +85°C)				
	NOTE: Ability to reach RH extremes may be limited by the humidity sensor accuracy. Low Dew Point conditions can only be achieved when starting with a clean, dry chamber.				
Control Tolerance	±3% RH max., ±1% RH typical at 85% RH (Short-term variations measured at the control sensor after stabilization)				
<b>Display Resolution</b>	0.1% RH				
Humidity Sensor	Dynamic capacitive type (no wet wicks required)				

Cool Down Transition Time (empty, uncontrolled humidity mode)*						
End Temperature						
	+23°C	0°C	-20°C	-40°C	-55°C	-65°C
Time from +23°C: °C/minute:	_	4 min 5.8 °C/min	9 min 4.8°C/min	16 min 3.9°C/min	22 min 3.5°C/min	27 min 3.3°C/min
Time from +85°C: °C/minute:	10 min 8.5°C/min	16 min 5.3℃/min	23 min 4.6°C/min	30 min 4.2°C/min	36 min 3.9°C/min	42 min 3.3°C/min

## Heat Up Transition Time (empty, uncontrolled humidity mode)\*

-40°C to +85 °C 25 minutes (5°C/minute)

\*Note: Transition times are measured after a 2 hour soak at the respective start temperature with an empty chamber, as indicated on the temperature controller, 23°C ambient. Measured with setpoint beyond the start and end temperatures. Does not include the effect of proportional band when approaching setpoint. Performance is reduced by 17% with 50Hz input power.

Live Load Capacity (uncontrolled humidity mode)					
+23°C	0°C	-20°C	-40°C	-55°C	-65°C
2,900 Watts	2,600 Watts	2,300 Watts	1,750 Watts	1,450 Watts	1,050 Watts

Low Stage Refrigerant	R-508B (Dupont SUVA-95)
Compressors	3.5 HP x 3.5 HP Copeland scroll compressors in a cascade configuration <u>More about Scroll Compressors</u> >>
Condenser	Air Cooled
Heat of Rejection	27,500 BTUH (maximum rated chamber load at maximum cooling rate from high temperature soak)
Heater Power	4,200 Watts @ 208 V input
Air Flow	830 cfm
Instrumentation	
Temp/Humidity Controller	Watlow F4T Touch Screen Controller with RS-232, Ethernet interface, 4.3" color graphic touch screen. OR Watlow F4 Controller with RS-232 interface, LED readout of temperature, LCD display of other parameters.
Limit Controller	Independent high and low temperature limits. Triggers an audible alarm and shuts down the chamber. Relay contacts provide a safety power interlock for test sample.
Chart Recorder	(Optional) Honeywell DR4300 Series. Two pen, 10" circular chart. Mounts in lower front door.

Input Power Requirements	
230 V ±10%, 60 Hz, 3 Phase	Max Current Draw 39 A; Recommended Service 50 A
208 V -5/+10%, 60 Hz, 3 Phase	Max Current Draw 35 A; Recommended Service 45 A
	Input may be configured for 230 V or 208 V in the field by changing jumpers. Three phase load is balanced.
	Call for other voltages or 50Hz operation. Performance is reduced by 17% with 50Hz input power.
	Customer power source must be hard-wired to the chamber by a qualified electrician. Power cord and plug
	is not included.
Physical Characteristics and	Safety
Inside Dimensions	40" W x 32" H x 36.5" D (27 cubic feet)
	1016 mm W x 813 mm H x 927 mm D (765 liters)
Outside Dimensions	49" W x 79.5" H x 67" D (nominal)
	1245 mm W x 2019 mm H x 1702 mm D
	Door latch adds 3" to width on right side.

Minimum Installed Clearance	12" from the left and right side 24" from the rear
Window Viewing Area	18" W x 12" H
Access Ports	4" Port on left and right side (two total). Supplied with foam plugs.
Weight	Chamber Weight: 1,600 pounds Shipping Weight: 1,784 pounds
Sound Level	68 dBA in cooling mode (A-weighted, measured 36" from the front surface, 63" from the floor, in a free-standing environment)

**NOTE:** Performance is typical and based on operation at 23°C (73°F) ambient and nominal input voltage. Designed for use in a normal conditioned laboratory. Operation at higher ambient temperatures may result in decreased cooling performance. Additional ports and shelves will also affect performance. Operation above 30°C (85°F) or below 16°C (60°F) ambient is not recommended.

Due to continuous product improvements, specifications subject to change without notice.

https://www.testequity.com/1027H-specs

Copyright  $\ensuremath{\mathbb{C}}$  2023 TestEquity LLC, All rights reserved.